	Type	Thread	Tightening specification	Measure
1AZ Vent valve	E81, E82, E87, E88, E90, E91, E92, E93	wrench size 9 mm		7-11 Nm
	E81, E82, E87, E88, E90, E91, E92, E93	wrench size 11 mm		12-18 Nm

	Type	Thread	Tightening specification	Measure
1AZ Brake disc to wheel hub	E81, E82, E87, E88, E90, E91, E92, E93			16 Nm
2AZ Brake anchor plate to swivel bearing	E81, E82, E87, E88, E90, E91, E92, E93	M12x1.5		110 Nm
3AZ Guard plate to swivel bearing	E81, E82, E87, E88, E90, E91, E92, E93	M6		12 Nm
4AZ Guide screw (socket head cap screw)	E81, E82, E87, E88, E90, E91, E92, E93	WAF 7		30 Nm
5AZ Guide screw (hexagon screw)	E81, E87, E90	WAF 13	Replace screws	35 Nm

	Type	Thread	Tightening specification	Measure
1AZ Brake disc to wheel hub	E81, E82, E87, E88, E90, E91, E92, E93			16 Nm
2AZ Brake caliper to wheel carrier	E81, E82, E87, E88, E90, E91, E92, E93			65 Nm
3AZ Protective plate to wheel carrier	E81, E82, E87, E88, E90, E91, E92, E93	M6		12 Nm
	E81, E82, E87, E88, E90, E91, E92, E93	M8		15 Nm
4AZ Guide screw (socket head cap screw)	E81, E82, E87, E88, E90, E91, E92, E93	WAF 7		30-5 Nm
5AZ Guide screw (hexagon screw)	E81, E87, E90, E91	WAF 13	Replace screws	35 ±3 Nm

	Type	Thread	Tightening specification	Measure
1AZ Brake master cylinder to brake booster (vacuum)	E81, E82, E87, E88, E90, E91, E92, E93	M8	Replace self-locking nuts	21 ±3 Nm

	Type	Thread	Tightening specification	Measure
1AZ Brake line screws / union screws	E81, E82, E87, E88, E90, E91, E92, E93	M12 x 1		12 Nm
2AZ Brake hose to brake caliper, front	E81, E82, E87, E88, E90, E91, E92, E93			24 ± 2 Nm
3AZ Brake hose to brake caliper, rear	E81, E82, E87, E88, E90, E91, E92, E93			24 ± 2 Nm

	Type	Thread	Tightening specification	Measure
1AZ Brake booster to pedal assembly console	E81, E82, E87, E88, E90, E91, E92, E93	M8	Retighten 1x after 5 minutes on brake booster	22 Nm

	Type	Thread	Tightening specification	Measure
1AZ Handbrake lever to body	E81, E82, E87, E88, E90, E91, E92, E93			21 Nm
2AZ Spring clip to wheel carrier	E81, E82, E87, E88, E90, E91, E92, E93	M6		8 Nm
3AZ Support Duo-Servo to wheel carrier, rear	E81, E82, E87, E88, E90, E91, E92, E93	M8		15 Nm
4AZ Guide tube to body	E81, E82, E87, E88, E90, E91, E92, E93	M6		8 Nm
5AZ Bracket, centre console	E81, E82, E87, E88, E90, E91, E92, E93	M6		8 Nm

	Type	Thread	Tightening specification	Measure
1AZ Bearing pedestal to brake assembly and body	E81, E82, E87, E88, E90, E91, E92, E93	M8	Retighten 1x on brake booster after 5 min	21 Nm
	E81, E82, E87, E88, E90, E91, E92, E93	M6		8 Nm

	Type	Thread	Tightening specification	Measure
1AZ Control unit on hydraulic unit	MK60, E81, E82, E87, E88, E90, E91, E93			5+1 Nm
	MK60E5, E90, E91, E92, E93			2 ± 1 Nm
2AZ DSC sensor to holder	E81, E82, E87, E88, E90, E91, E92, E93			8 Nm
3AZ Bracket, DSC sensor, to body	E81, E82, E87, E88, E90, E91, E92, E93			8 Nm
4AZ Pulse generator to swivel bearing/wheel carrier	E81, E82, E87, E88, E90, E91, E92, E93			8 Nm
5AZ Bracket to hydraulic unit	E81, E82, E87, E88, E90, E91, E92, E93			8 Nm
6AZ Bracket, hydraulic unit to body	E81, E82, E87, E88, E90, E91, E92, E93			8 Nm

	Type	Thread	Tightening specification	Measure
1AZ Control unit on hydraulic unit	MK60, E81, E82, E87, E88, E90, E91, E93			5+1 Nm
	MK60E5, E90, E91, E92, E93			2 ± 1 Nm
2AZ DSC sensor to holder	E81, E82, E87, E88, E90, E91, E92, E93			8 Nm
3AZ Bracket, DSC sensor, to body	E81, E82, E87, E88, E90, E91, E92, E93			8 Nm
4AZ Pulse generator to swivel bearing/wheel carrier	E81, E82, E87, E88, E90, E91, E92, E93			8 Nm
5AZ Bracket to hydraulic unit	E81, E82, E87, E88, E90, E91, E92, E93			8 Nm
6AZ Bracket, hydraulic unit to body	E81, E82, E87, E88, E90, E91, E92, E93			8 Nm